

---

## SECTION VII - SPILL OR LEAK PROCEDURES

---

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED: Evacuate non essential personnel. Remove all sources of ignition (sparks, flames, hot surfaces). Ventilate the area. Equip clean up crew with self contained breathing apparatus. Dike spill. Cover with sawdust, vermiculite, Fuller's earth. Collect material in open containers.

### WASTE DISPOSAL METHOD:

Conform to federal, state, and local regulations. Empty containers must be handled carefully due to product residue and flammable solvent vapor.

---

## SECTION VIII - SAFE HANDLING AND USE INFORMATION

---

RESPIRATORY PROTECTION: In outdoor or open areas use NIOSH approved mechanical filter respirator. In restricted ventilation areas, use NIOSH approved chemical/mechanical filters to remove vapor and particulates. In confined areas use NIOSH approved air line type respirators or hoods.

VENTILATION: Must be sufficient in volume and pattern to keep contaminant concentration below TLV (NIOSH) or PEL (OSHA).

PROTECTIVE GLOVES: Required, butyl rubber recommended.

EYE PROTECTION: Required. Use goggles, face shields or safety eyewear with sideshields.

OTHER PROTECTIVE EQUIPMENT: Protective creams where skin contact is likely.

HYGIENIC PRACTICES: Wash hands before eating or using bathroom. Remove and wash contaminated clothing before reuse. Wear chemical resistant boots.

---

## SECTION IX - SPECIAL PRECAUTIONS

---

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING: Do not store above 100°F. Store large quantities only in buildings designed to comply with OSHA 1910.106. Keep containers closed and upright to prevent leakage. Do not store or use near heat, sparks, or flames.

OTHER PRECAUTIONS: Avoid breathing sanding dust (respirator required). Avoid prolonged or repeated contact with vapor or spray mist during application or curing.

---